# **bmf** system parts

# Genesys™

Programmable DC Power Supplies
3.3kW in 2U
Built in RS-232 & RS-485 Interface
Advanced Parallel Operation
Optional Interface:
LXI Compliant LAN
IEEE488.2 SCPI (GPIB) Multi-Drop
Isolated Analog Programming



Genesys™ Family GENH 750W Half Rack GEN1U 750/1500/2400W Full Rack GEN2U 3.3/5kW

TDK-Lambda



The Genesys™ family of programmable power supplies sets a new standard for flexible, reliable, AC/DC power systems in OEM, Industrial and Laboratory applications.

#### **Features include:**

- High Power Density 3.3kW in 2U
- Wide Range of popular worldwide AC inputs, 1ø (230VAC) & 3ø (208VAC, 400VAC)
- Active Power Factor Correction (Single-Phase & Three-Phase AC Input)
- · Output Voltage up to 600V, Current up to 400A
- Built-in RS-232/RS-485 Interface Standard
- Global Commands for Serial RS-232/RS-485 Interface
- Auto-Re-Start / Safe-Start: user selectable
- Last-Setting Memory
- High Resolution 16 bit ADCs & DACs
- Low Ripple & Noise
- Front Panel Lock selectable from Front Panel or Software
- Reliable Encoders for Voltage and Current Adjustment
- Constant Voltage/Constant Current auto-crossover
- Parallel Operation with Active Current Sharing; up to four identical units.
- Advanced Parallel Master / Slave. Total Current is Programmed and Measured via the Master.
- Independent Remote ON/OFF and Remote Enable/Disable
- External Analog Programming and Monitoring (user selectable 0-5V & 0-10V)
- Reliable Modular and SMT Design
- 19" Rack Mount capability for ATE and OEM applications
- Optional Interfaces
   Isolated Analog Programming and Monitoring Interface (0-5V/0-10V & 4-20mA)

   IEEE 488.2 SCPI (GPIB) Multi-Drop

#### **LXI** Compliant LAN

- LabView® and LabWindows® drivers
- Five Year Warranty

Worldwide Safety Agency Approvals; CE Mark for LVD and EMC Regulation





#### **Applications**

Genesys<sup>™</sup> power supplies have been designed to meet the demands of a wide variety of applications.

Test & Measurement systems, Component Device Testing.

Semiconductor Processing & Burn-In, Aerospace & Satellite Testing, Medical Imaging, Green Technology.

System Designers will appreciate new, standard, remote programming features such as Global commands. Also, new high-speed status monitoring is available for the RS-485 bus.

**Test Systems** using the IEEE-488 bus may achieve significant cost savings by incorporating the Optional IEEE Multi-Drop Interface for a Master and up to 30 RS-485 Multi-Drop Slaves.

**Higher power systems** can be configured with up to four 3.3kW modules. Each module is 2U with zero space between them (zero stack).

Flexible configuration is provided by the complete Genesys™ Family: 1U 750W Half-Rack, 1U 750W, 1500W and 2400W Full-Rack. All are identical in Front Panel, Rear Panel Analog, and all Digital Interface Commands.

**OEM Designers** have a wide variety of Inputs and Outputs from which to select depending on application and location.



#### **Front Panel Description**



- 1. ON/OFF Switch
- 2. Air Intake allows zero stacking for maximum system flexibility and power density.
- 3. Reliable encoder controls Output Voltage, Address, OVP and UVL settings.
- 4. Volt Display shows Output Voltage and directly displays OVP, UVL and Address settings.
- 5. Reliable encoder controls Output Current, sets baudrate and Advanced Parallel mode.
- 6. Current Display shows Output Current and displays Baud rate. Displays total current in Parallel Master/Slave Mode
- 7. Function/Status LEDs:
- Alarm Fine Control Preview Settings
- Foldback Mode Remote Mode Output On
- 8. Pushbuttons allow flexible user configuration
  - Coarse and Fine adjustment of Output Voltage/Current and Advanced Parallel Master or Slave
  - Preview settings and set Voltage/Current with Output OFF, Front Panel Lock
  - Parallel Master/Slave
  - Set OVP and UVL Limits
  - Set Current Foldback Protection
  - Go to Local Mode and select Address and Baud rate
  - Output ON/OFF and Auto-Re-Start/Safe-Start Mode

#### **Rear Panel Description**



- 1. Remote/Local Output Voltage Sense Connections.
- 2. DIP Switches select 0-5V or 0-10V Programming and other functions.
- 3. DB25 (Female) connector allows (Non-isolated) Analog Program and Monitor and other functions.
- 4. RS-485 OUT to other Genesys™ Power Supplies.
- 5. RS-232/RS-485 IN Remote Serial Programming.
- 6. Output Connections: Rugged busbars (shown) for up to 100V Output; wire clamp connector for Outputs >100V.
- 7. Exit air assures reliable operation when zero stacked.
- 8. Input: 230VAC Single Phase (shown), 208 & 400VAC Three Phase, 50/60 Hz AC Input Connector: PHOENIX CONTACT Power Combicon PC 6/... Series with strain relief.
- 9. Optional Interface Position for IEEE 488.2 SCPI (shown) or Isolated Analog Interface or LAN Interface.



#### Genesys ™ 3.3kW Specifications

1.0 MODEL MODEL 1.Rated output	t									Si	pecificat	ions in bl	ue are im	proved									
voltage(*1) 2.Rated Output Current(*2	) GFN	8-400	10-330	15-220 2	20-165 3	0-110	40-85	60-55	80-42			200-16.5											
3.Rated Output Power 1.1 CONSTAN' VOLTAGE MODE 1.Max.line regulation	V	8	10	15	20	30	40	60	80	100	150	200	300	600									
0.01% of rated Vo+ 2mV )(*6) 2.Max load		400	330	220	165	110	85	55	42	33	22	16.5	11	5.5									
regulation ( 0.015% of rated Vo+5mV )(*7		3200 2.8	3300 3	3300 3.5	3300 4	3300 5	3400 6	3300 8	3360 10	3300 12	3300	3300 22	3300 32	3300 62									
3. Ripple and noise p-p 20MHz (*8) 4. Ripple	e m\/	6.2	6.5	7.25	8	9.5	11	14	17	20	17 27.5	35	50	95									
r.m.s 5Hz~1MHz 5.Remote sense	<del>-</del>	55	55	55	55	55	55	60	70	100	100	275	300	350									
compensation/wire 6.Temp. coefficien 7.Temp. stability 8.Warm-up drift 9.Up-proc		- 8	- 8	7	7	7	7	7	20	25	20	70	80	80									
response time, 0~Vo Rated (*9)	J. V	2	2	2	2	5	5	5	5	5	5	5	5	5									
	PPM/°C	50PPM/	°C of rat	ed outp	ut voltag	je,follow	ring 30 r	ninutes v	warm-up	)													
		0.01% o	f rated V	out over	8hrs int	erval fol	lowing 3	80 minute er 30 mir	es warm	-up. Con	stant lin	e, load & t	temp.										
	mS	Less ma	11 0.05%		0 0	voitage	-21110 00	er 30 mii		50	ower Or	1.	20	250									
10.Down-prog response Full-load (*9)	mS	20		100	0		160		- 1.	30	300	20	JO	500									
time No-load (*10)	mS	500	600	700	800	900	1000	1100	1200	1500	2000	3000	3500	4000									
11 Tong in the control of the control	mS	Time for	output	voltage	to recov	er withir	0.5% of	its rated	output	for a loa	d chang	e 10-90%	of rated	output									
11.Transient response time	1113	set-poir	ht: 10-10	0%. loca	l sense. I	ess thai	n 1mSec	for mod	els un to	and inc	ludina 1	00V. 2ms	sec for mo	odels al									
1.2 CONSTANT CURRENT MODE																							
1.Max.line regulation (0.01% of rated lo+2mA 2.Max.load regulation (0.02% of rated lo+5mA	)(*BA	42	35	24	18.5	13	10.5	7.5	6.2	5.3	4.2	3.65	3.1	2.6									
2.Max.load regulation (0.02% of rated lo+5m/	(*/11/h)	85 1000	71 650	49 400	38 300	27 250	22 150	16 70	13.4 60	11.6 50	9.4 20	8.3 30	7.2	6.1 8									
3.htppie 1.111.5 3nz~ Hvinz . (**12)	,							ninutes fo				30											
4.Load regulation thermal drift 5.Temp. coefficient	PPM/°C							0 minut			9~.												
6.Temp. stability											stant lin	e, load &	tempera	ture.									
7.Warm-up drift		8V~20V	models	Less th	an ±0.5%	of rate	doutnu	current	over 30	minutes	followir	ng power	On.										
•		30Y260	oy mod	ls:Less	than ±0.	25% of	ated ou	tput cur	rent ove	r 30 min	utes foll	owing po	wer On.										
1.3 PROTECTIVE FUNCTIONS 1. OCP								rom CV t															
2. OCP Foldback		Inverter	shut-do	wn, mai	nual rese	t by AC	input re	cycle or	by OUT	button c	r by con	nmunicat	ion port	comma									
3. OVP type																							
4. OVP trip point								5~66V5					5~330V	5~660V									
5. Output Ünder Voltage Limit 6. Over Temp. Protection								events fr	om adju	sting Vo	ut belov	v limit.											
1.4 ANALOG PROGRAMMING AND MONITO	RING	l			or non-																		
1.Vout Voltage Programming								nd lineari															
2.lout Voltage Programming (*13) 3.Vout Resistor Programming		0~100%	$0.0^{-5}$	or 0~10V	, user se	ect. Acc	uracy ar	nd lineari	ty:±1% (	of rated	out.	/out											
4.lout Resistor Programming (*13)								racy and															
5.On/Off control (rear panel)			rical. Vo	ltage: 0~	-0.6V/2~	15V,or c	lry conta	ct ,user	selectab	le logic.	orracea	lout.											
6.Output Current monitor (*13)	By electrical. Voltage: 0~0.6V/2~15V,or dry contact ,user selectable logic. 0~5V or 0~10V , Accuracy:±1% , user selectable.																						
7.Output Voltage monitor 8.Power Supply OK signal	0~5V or 0~10V ,Accuracy:±1% ,user selectable.																						
9. CV/CC Indicator			TTL high (4~5V) -OK, 0V-Fail 500ohm series resistance. Open collector, CC mode: On, CV mode: Off, Maximum voltage: 30V, maximum sink current: 10mA																				
10. Enable/Disable		Dry con	tact. Op	en:off, S	hort: on	. Max. vo	oltage at	Enable/	Disable	in: 6V.			Dry contact. Open:off , Short: on. Max. voltage at Enable/Disable in: 6V.										
11. Local/Remote analog control		By elect	rical sigr	nal or Op	en/Shor	t: 0~0.6	By electrical signal or Open/Short: 0~0.6V or short: Remote, 2~15V or open: Local.																
		Open follerfar Lacabi Off the spots are Maxims moyaltage 3 Alxerantin legerrante 10 ma.																					
12. Local/Kemote analog control Indicator 1.5 FRONT PANEL		April) (9	ut manu	iai adjus	t by sep	arate en	<del>laximur</del>	<del>coarse a</del> f	nd fine a	aximum	n: Local. sink cu nt selec	rent: 10n	nA.										
12. Local/Remote analog control Indicator 1.5 FRONT PANEL		OVP/UV	'L manua	al adjust	by Volt.	Adjust e	ncoder.			aximum	nt selec	rent: 10n											
1.2. Local/Remote analog control Indicator 1.5 FRONT PANEL		OVP/UV On/Off,	L manua Output	al adjust on/off, R	by Volt. e-start n	Adjust e nodes (a	ncoder. uto, safe	e), Foldb	ack cont	azimme rol (CV t	sink cu nt selec o CC), Go	table). <sup>10n</sup> o to local											
12. Local/Remote analog control Indicator 1.5 FRONT PANEL		OVP/UV On/Off, Address Re-start	L manua Output selectic modes	al adjust on/off, R on by Vo (automa	by Volt. e-start n ltage (or tic resta	Adjust e nodes (a current rt, safe r	ncoder. uto, safe adjust node).	e), Foldba encoder.	ack cont	azimme rol (CV t	sink cu nt selec o CC), Go	table). <sup>10n</sup> o to local											
1.5 FRONT PANEL		OVP/UV On/Off, Address Re-start	L manua Output selectic modes	al adjust on/off, R on by Vo (automa	by Volt. e-start n	Adjust e nodes (a current rt, safe r	ncoder. uto, safe adjust node).	e), Foldba encoder.	ack cont	azimme rol (CV t	sink cu nt selec o CC), Go	table). <sup>10n</sup> o to local											
12. Local/Remote analog control Indicator 1.5 FRONT PANEL  1. Control functions		OVP/UV On/Off, Address Re-start Baud ra	L manua Output selectic modes te select	al adjust on/off, R on by Vo (automa ion: 120	by Volt. e-start n Itage (or tic resta 0,2400,4	Adjust e nodes (a current rt, safe r 800,960	ncoder. uto, safe adjust node). 0 and 19	e), Foldba encoder. 9,200.	ack cont Numbe	rol (CV to r of addr	sink cu nt selec o CC), Go	table). <sup>10n</sup> o to local											
1.5 FRONT PANEL		OVP/UV On/Off, Address Re-start Baud ra Voltage Current	L manual Output of Selection Modes te selection : 4 digits: 4 digits: 4 digits:	al adjust on/off, R on by Vo (automa ion: 120 a, Accura	by Volt. re-start natage (or stic resta 0,2400,4 acy: 0.05 cy: 0.2%	Adjust enodes (a current rt, safe r 800,960 % of rate of rated	ncoder. uto, safe adjust node). 0 and 19 ed output	e), Foldba encoder. 9,200. ut Voltag	eck cont Numbe	rol (CV to r of addr unt.	o CC), Go esses:31	rrent: 10n able). o to local	control.										
1.5 FRONT PANEL		OVP/UV On/Off, Address Re-start Baud ra Voltage Current	L manual Output of Selection Modes te selection : 4 digits: 4 digits: 4 digits:	al adjust on/off, R on by Vo (automa ion: 120 a, Accura	by Volt. re-start natage (or stic resta 0,2400,4 acy: 0.05 cy: 0.2%	Adjust enodes (a current rt, safe r 800,960 % of rate of rated	ncoder. uto, safe adjust node). 0 and 19 ed output	e), Foldba encoder. 9,200. ut Voltag	eck cont Numbe	rol (CV to r of addr unt.	o CC), Go esses:31	table). <sup>10n</sup> o to local	control.										
1.Control functions		OVP/UV On/Off, Address Re-start Baud ra Voltage Current	L manual Output of Selection Modes te selection : 4 digits : 4 digits : 4 digits	al adjust on/off, R on by Vo (automa ion: 120 a, Accura	by Volt. re-start natage (or stic resta 0,2400,4 acy: 0.05 cy: 0.2%	Adjust enodes (a current rt, safe r 800,960 % of rate of rated	ncoder. uto, safe adjust node). 0 and 19 ed output	e), Foldba encoder. 9,200. ut Voltag	eck cont Numbe	rol (CV to r of addr unt.	o CC), Go esses:31	rrent: 10n able). o to local	control.										
1.Control functions 2.Display		OVP/UV On/Off, Address Re-start Baud ra Voltage Current	L manual Output of Selection Modes te selection : 4 digits : 4 digits : 4 digits	al adjust on/off, R on by Vo (automa ion: 120 a, Accura	by Volt. re-start natage (or stic resta 0,2400,4 acy: 0.05 cy: 0.2%	Adjust enodes (a current rt, safe r 800,960 % of rate of rated	ncoder. uto, safe adjust node). 0 and 19 ed output	e), Foldba encoder. 9,200. ut Voltag	eck cont Numbe	rol (CV to r of addr unt.	o CC), Go esses:31	rrent: 10n able). o to local	control.										
1.Control functions 2.Display 3.Indications	C Couise	OVP/UV On/Off, Address Re-start Baud ra Voltage Current Voltage	L manua Output selectic modes te select : 4 digits : 4 digits	al adjust on/off, R on by Vo (automa ion: 120 s., Accura , Accura t, Alarm,	by Volt. te-start n ltage (or tic resta 0,2400,4 acy: 0.05 cy: 0.2% Fine, Pr	Adjust enodes (a current rt, safe r 800,960 % of rate of rated eview, F	encoder. uto, safe adjust node). 0 and 19 ed output output oldback	encoder. 9,200. ut Voltag current : Local, C	e ±1 count butput O	rol (CV to r of addr unt.	o CC), Go esses:31	rrent: 10n able). o to local	control.										
1.Control functions  2.Display 3.Indications  1.6 Interface Specifications for the GENESY		OVP/UV On/Off, Address Re-start Baud ra Voltage Current Voltage	L manua Output s selectic modes te select : 4 digits , Curren	al adjust on/off, R on by Vo (automa ion: 120 c, Accura t, Alarm,	by Volt. te-start n Itage (or tic resta 0,2400,4 acy: 0.05 cy: 0.2% Fine, Pr	Adjust enodes (a current rt, safe r 800,960 % of rated eview, F	encoder. uto, safe adjust node). 0 and 19 ed output output oldback	e), Foldbach encoder. 9,200. ut Voltag current : Local, C	ack cont Numbe le ±1 cou ±1 coun output O	agiistine rof (CV t r of addr unt. t. n, Front	nitselect o CC), Go esses:31 Panel Lc	o to local	control.										
1.Control functions  2.Display 3.Indications 1.6 Interface Specifications for the GENESY 1. Remote Voltage Programming (16 bit)	V	OVP/UV On/Off, Address Re-start Baud ra Voltage Current Voltage	L manua Output: selectic modes te select : 4 digits : 4 digits , Curren	al adjust on/off, R in by Voi (automa ion: 120 in, Accura in, Accura in, Accura in, Accura in, Accura in, Accura	by Volt. e-start n Itage (or tic resta 0,2400,4 acy: 0.05 cy: 0.2% Fine, Pri	Adjust condes (a current rt, safe r 800,960 % of rated eview, F	encoder: uto, safe adjust inode). 0 and 19 ed output output oldback	e), Foldbercoder.  9,200.  ut Voltag current: Local, C	ack continumbe  le ±1 countinutput O  stalled	rol (CV trofaddr	nitselect o CC), Gesses:31 Panel Lc	o to local	control.	600									
1.Control functions  2.Display 3.Indications  1.6 Interface Specifications for the GENESY 1. Remote Voltage Programming (16 bit) Resolution (0.002% of Vo Rated)		OVP/UV On/Off, Address Re-start Baud ra Voltage Current Voltage	L manua Output s selectic modes te select : 4 digits , Curren	al adjust on/off, R on by Vo (automa ion: 120 c, Accura t, Alarm,	by Volt. te-start n Itage (or tic resta 0,2400,4 acy: 0.05 cy: 0.2% Fine, Pr	Adjust enodes (a current rt, safe r 800,960 % of rated eview, F	encoder. uto, safe adjust node). 0 and 19 ed output output oldback	e), Foldbach encoder. 9,200. ut Voltag current : Local, C	ack cont Numbe le ±1 cou ±1 coun output O	agiistine rof (CV t r of addr unt. t. n, Front	nitselect o CC), Go esses:31 Panel Lc	o to local	control.	600									
1.Control functions  2.Display 3.Indications 1.6 Interface Specifications for the GENESY 1. Remote Voltage Programming (16 bit) Resolution (0.002% of Vo Rated) Accuracy (0.05% of Vo Rated) (*14)	V mV	OVP/UV On/Off, Address Re-start Baud ra Voltage Current Voltage	L manua Output - s selectic modes- te select : 4 digits : 4 digits ; Curren	al adjust on/off, R on by Voi (automa ion: 120 a , Accura , Accura t, Alarm,	by Volt. e-start n ltage (or itic resta 0,2400,4 0,2400,7 Fine, Pr	Adjust enodes (a current rt, safe r 800,960 % of rated eview, F	encoder. uto, safe adjuste node). 0 and 19 ed output output oldback	e), Foldberncoder.  2,200.  ut Voltag current: Local, C	e ±1 country to the stalled 80 1.6	rol (CV trof addr	Panel Lo	o to local  ock, CVCC	300 6	12									
1.Control functions  2.Display 3.Indications 1.6 Interface Specifications for the GENESY 1. Remote Voltage Programming (16 bit) Resolution (0.002% of Vo Rated) ACCUracy (0.05% of Vo Rated) (*14) 2. Remote Current Programming (16 bit) Resolution (0.002% of fo Rated)	mV mV	OVP/UV On/Off, Address Re-start Baud ra Voltage Current Voltage	L manua Output is selectic modes te select : 4 digits : 4 digits ; Curren	al adjust on/off, R on by Voi (automa ion: 120 , Accura , Accura , Accura , Accura , Accura , Oi i-485 Or 0.3 8	by Volt. e-start n ltage (or tic resta 0,2400,4 acy: 0.05 cy: 0.2% Fine, Pro  Option: 20 0.4 10	Adjust enodes (accurrent rt, safe r 1800,960 % of rated eview, F	encoder. uto, safe ) adjust node). 0 and 19 ed output output oldback	e), Foldbencoder.  2,200.  ut Voltag current: Local, C  60 1.2 30	stalled 80 1.6 40	agyistime crof (CV tr r of addr unt. t. m, Front	Panel Lo	creati; 10n o to local	300 6 150	12 300 0.11									
1.Control functions  2.Display 3.Indications 1.6 Interface Specifications for the GENESY 1. Remote Voltage Programming (16 bit) Resolution (0.002% of Vo Rated) ACCUracy (0.05% of Vo Rated) (*14) 2. Remote Current Programming (16 bit) Resolution (0.002% of lo Rated) Accuracy (0.2% of lo Rated) Accuracy (0.2% of lo Rated)	MV mV	OVP/UV On/Off, Address Re-start Baud ra Voltage Current Voltage	L manua Output is s selectic modes te selectic 4 digits 4 digits Curren	al adjust on/off, Ro on by Voi (automa ion: 120 , Accura , Accura t, Alarm,	by Volt. e-start n ltage (or tic resta 0,2400,4 acy: 0.05 cy: 0.2% Fine, Pr	Adjust enodes (a current rt, safe r 800,960 % of rate deview, F	encoder. uto, safe adjuste node). 0 and 19 ed output output oldback	e), Foldb. encoder. 9,200. ut Voltag current : Local, C	e ±1 counturbut O  stalled 80 1.6 40	advistme rof (CV trof addr unt. t. n, Front	Panel Lc	o to local  bock, CVCC	300 6 150	12 300									
1.Control functions  2.Display 3.Indications 1.6 Interface Specifications for the GENESY 1.Remote Voltage Programming (16 bit) Resolution (0.002% of Vo Rated) Accuracy (0.05% of Vo Rated) 4.Curacy (0.05% of Vo Rated) (*14) 2. Remote Current Programming (16 bit) Resolution (0.002% of lo Rated) Accuracy (0.2% of lo Rated +0.1% of lo Actual +0.1% of lo Act	MV mV mA	OVP/UV On/Off, Address Re-start Baud ra Voltage Current Voltage	L manua Output is selectic reselectic modes te select : 4 digits : 4 digits ; Curren : -232/RS 10 0.2 5	al adjust on/off, R on/off, R on by Voi (automa ion: 120 . , Accura t, Accura t, Alarm,	by Volt. e-start n ttage (or tic resta 0,2400,4 acy: 0.05 cy: 0.29 Fine, Pr   Option: 20 0.4 10  3.3 495	Adjust enodes (a courrent rt, safe r 800,960 % of ratio of rated eview, F 30 0.6 15 2.2 330	encoder. uto, safe ) adjust in node). 0 and 19 ed output output oldback, 40 0.8 20	e), Foldbencoder.  2),200.  ut Voltage ut Voltage Local, C  erface In  60  1.2  30  1.1	stalled 80 1.6 40 0.84	agistime rol (CV tr of addr	### Section	200 4 100 0.33 49.5	300 6 150	0.11 16.5									
1.Control functions  2.Display 3.Indications 1.6 Interface Specifications for the GENESY 1. Remote Voltage Programming (16 bit) Resolution (0.002% of Vo Rated) Accuracy (0.05% of Vo Rated) (*14) 2. Remote Current Programming (16 bit) Resolution (0.002% of lo Rated) Accuracy (0.2% of lo Rated) (*0.002% of lo Rated) Accuracy (0.2% of lo Rated) Resolution (% of Vo Rated) Resolution (% of Vo Rated) Resolution (% of Vo Rated)	W mV mV mA Dutsput)	OVP/UV On/Off, Address Re-start Baud ra Voltage Current Voltage  ***with RS  0.16 4  (**1200	L manua Output is selectic in selectic modes to select sel	al adjust on/on/on/on/on/on/on/on/on/on/on/on/on/o	by Volt. e-start n trage (or tric resta 0,2400,4 acy: 0.05 cy: 0.29 Fine, Pr  Optiona 20 0.4 10  3.3 495	Adjust en odes (a courrent rt, safe r 800,960 % of rate of rated eview, F 30 0.6 15 32 2.2 330 0.004	uto, safet adjust in ode). 0 and 19 ed output oldback  LAN Into 40 0.8 20 1.7 255	e), Foldbencoder.	ack conti-Numbe  le ±1 countinutput O  stalled  80  1.6  40  0.84  126  0.002	100 2 50 0.66 99	nitiselector of CC), Gresses:31  Panel Lo  150 3 75  0.44 66  0.007	200 4 100 0.33 49.5	300 6 150 0.22 33	0.11 16.5									
1.Control functions  2.Display 3.Indications 1.6 Interface Specifications for the GENESY 1. Remote Voltage Programming (16 bit) Resolution (0.002% of Vo Rated) Accuracy (0.05% of Vo Rated) (*14) 2. Remote Current Programming (16 bit) Resolution (0.002% of lo Rated) Accuracy (0.2% of lo Rated) (*0.002% of lo Rated) Accuracy (0.2% of lo Rated) Resolution (% of Vo Rated) Resolution (% of Vo Rated) Resolution (% of Vo Rated)	MV mV mA Output)	OVP/UV On/Off, Address Re-start Baud ra Voltage Current Voltage  with RS 8 0.16 4 (*1200	L manua Output: selectic modes te select: : 4 digits: : 4 digits: ; Curren: -232/RS 10 0.2 5 6.6 990	al adjust on/off, R on/off, Accura , Accu	by Volt. e-start n trage (or n tic resta 0,2400,4 acy: 0.055 cy: 0.2% Fine, Pr  Optiona 20 0.4 10  3.3 495	Adjust enodes (a courrent rt, safe r 800,960 % of rated eview, F	uto, safe to adjust to node). 0 and 19 ed output output oldback	e), Foldberncoder.  2),200.  41 Voltage current:  4 Local, Company current:  5 Local, Company current:  60 1.2 30 1.1 165 1.2 1.2 1.2 1.2 1.2 1.2 1.2 1.2 1.2 1.2	stalled  80 1.6 40  0.84 126	not (CV to rof address of address	150 3 75 0.44 66	200 4 100 0.33 49.5	300 6 150 0.22 33	0.11 16.5 0.002 12.00									
1.Control functions  2.Display 3.Indications 1.6 Interface Specifications for the GENESY 1. Remote Voltage Programming (16 bit) Resolution (0.002% of Vo Rated) Accuracy (0.05% of Vo Rated) (*14) 2. Remote Current Programming (16 bit) Resolution (0.002% of lo Rated) Accuracy (0.2% of lo Rated) - Accuracy (0.2% of lo Rated) Accuracy (0.2% of lo Rated) Besolution (% of Vo Rated) Resolution (% of Vo Rated) Resolution (Readback Voltage) Accuracy (0.05% of Vo Rated)	W mV mV mA Dutsput)	OVP/UV On/Off, Address Re-start Baud ra Voltage Current Voltage  ***with RS  0.16 4  (**1200	L manua Output is selectic in selectic modes to select sel	al adjust on/on/on/on/on/on/on/on/on/on/on/on/on/o	by Volt. e-start n trage (or tric resta 0,2400,4 acy: 0.05 cy: 0.29 Fine, Pr  Optiona 20 0.4 10  3.3 495	Adjust en odes (a courrent rt, safe r 800,960 % of rate of rated eview, F 30 0.6 15 32 2.2 330 0.004	uto, safet adjust in ode). 0 and 19 ed output oldback  LAN Into 40 0.8 20 1.7 255	e), Foldbencoder.	ack conti-Numbe  le ±1 countinutput O  stalled  80  1.6  40  0.84  126  0.002	100 2 50 0.66 99	nitiselector of CC), Gresses:31  Panel Lo  150 3 75  0.44 66  0.007	200 4 100 0.33 49.5	300 6 150 0.22 33	0.11 16.5									
1.Control functions  2.Display 3.Indications 1.6 Interface Specifications for the GENESY 1. Remote Voltage Programming (16 bit) Resolution (0.002% of Vo Rated) Accuracy (0.05% of Vo Rated) (*14) 2. Remote Current Programming (16 bit) Resolution (0.002% of fo Rated) Accuracy (0.2% of lo Rated) (*14) 3. Readback Voltage Resolution (% of Vo Rated) Resolution (Readback Voltage) Accuracy (0.05% of Vo Rated) 4. Readback Current Resolution (% of lo Rated)	V mV mV mA Outpat) % mV	OVP/UV On/Off, Address Re-start Baud ra Voltage Current Voltage  with RS  8 0.16 4  (*1300  0.002 0.16 4	L manua Output is selectic rodes te selectic : 4 digits: : 4 digits: ; 4 digits: ; 7 digits: ; 6-232/RS 10 0.2 5 6.6 990 0.011 1.10 5	1 adjust on/off, R on/off, A ccurra , Accurra , Accurra t, Alarm,    6-485 Or    15	by Volt. e-start n trage (or tic resta 0,2400,4 acy: 0.05 cy: 0.2% Fine, Pro  Option: 20 0.4 10  3.3 495	Adjust en nodes (a current rt, safe r 800,960 % of rate of rat	uto, safe adjust uto, safe adjust uto, safe adjust uto, safe adjust uto adjus	e), Foldberncoder.  2),200.  2),200.  2),200.  2),200.  2),200.  2),200.  2),200.  300.  2),200.  300.  300.  300.	stalled  80 1.6 40  0.84 126  0.002 1.60 40	100 2 50 0.66 99	150 3 75 0.44 66	200 4 100 0.33 49.5 0.006 12.00	300 6 150 0.22 33	0.11 16.5 0.002 12.00 300									
1.Control functions  2.Display 3.Indications 1.6 Interface Specifications for the GENESY 1. Remote Voltage Programming (16 bit) Resolution (0.002% of Vo Rated) Accuracy (0.05% of Vo Rated) (*14) 2. Remote Current Programming (16 bit) Resolution (0.002% of lo Rated) Accuracy (0.2% of lo Rated) (*0.1% of lo Actual-1) 3. Readback Voltage Resolution (% of Vo Rated) Resolution (% of Vo Rated) Accuracy (0.05% of Vo Rated) 4. Readback Current Resolution (% of Vo Rated) 4. Readback Current Resolution (% of Vo Rated) Resolution (Readback Voltage) Resolution (Readback Voltage) Resolution (Readback Voltage)	W mV mV mV mV mV mV	OVP/UV On/Off, Address Re-start Baud ra Voltage Current Voltage	L manua Output is selectic modes- te selectic : 4 digits: : 4 digits: : 4 digits: ; Currem 0.2 5 6.6 990 0.011 1.10 5	1 adjust on/on/on/on/on/on/on/on/on/on/on/on/on/o	by Volt. e-start n trage (or tic resta 0,2400,4 acy: 0.02 Fine, Pr  Option: 20 0,4 10  3.3 495  0.006 1.20 10	Adjust en nodes (a current rt, safe r 800,960 rate of	ncoder. uto, safe adjust- node). 0 and 19 ed output oldback  LAN Inte 40 0.8 20  1.7 255  0.003 1.20 20	e), Foldbencoder.  2),200.  ut Voltage current: Local, C  60 1.2 30  1.1 165  0.002 1.20 30	stalled 80 1.6 40 0.002 1.60 40 0.002	100 2 50 0.66 99 0.011 11.00 50 0.004	150 3 75 0.44 66 0.007 75	200 4 100 0.33 49.5 0.006 12.00 0.007	300 6 150 0.22 33 0.004 12.00 150	0.11 16.5 0.002 12.00 300									
1.Control functions  2.Display 3.Indications 1.6 Interface Specifications for the GENESY 1. Remote Voltage Programming (16 bit) Resolution (0.002% of Vo Rated) Accuracy (0.05% of Vo Rated) (*14) 2. Remote Current Programming (16 bit) Resolution (0.002% of fo Rated) Accuracy (0.2% of fo Rated) Accuracy (0.2% of fo Rated) Besolution (% of Vo Rated) Resolution (% of Vo Rated) Accuracy (0.05% of Vo Rated) 4. Readback Current Resolution (% of Vo Rated) 4. Readback Current Resolution (% of Po Rated) Resolution (Readback Current) Resolution (Readback Current) Resolution (Readback Current)	V mV mV mA Outpat) % mV	OVP/UV On/Off, Address Re-start Baud ra Voltage Current Voltage  with RS  8 0.16 4  (*1300  0.002 0.16 4	L manua Output is selectic rodes te selectic : 4 digits: : 4 digits: ; 4 digits: ; 7 digits: ; 6-232/RS 10 0.2 5 6.6 990 0.011 1.10 5	1 adjust on/off, R on/off, A ccurra , Accurra , Accurra t, Alarm,    6-485 Or    15	by Volt. e-start n trage (or tic resta 0,2400,4 acy: 0.05 cy: 0.2% Fine, Pro  Option: 20 0.4 10  3.3 495	Adjust en nodes (a current rt, safe r 800,960 % of rate of rat	uto, safe adjust uto, safe adjust uto, safe adjust uto, safe adjust uto adjus	e), Foldberncoder.  2),200.  2),200.  2),200.  2),200.  2),200.  2),200.  2),200.  300.  2),200.  300.  300.  300.	stalled  80 1.6 40  0.84 126  0.002 1.60 40	100 2 50 0.66 99	150 3 75 0.44 66	200 4 100 0.33 49.5 0.006 12.00	300 6 150 0.22 33	0.11 16.5 0.002 12.00 300									
1.Control functions  2.Display 3.Indications 1.6 Interface Specifications for the GENESY 1. Remote Voltage Programming (16 bit) Resolution (0.002% of Vo Rated) Accuracy (0.05% of Vo Rated) (*14) 2. Remote Current Programming (16 bit) Resolution (0.002% of lo Rated) Accuracy (0.2% of lo Rated) (*14) 3. Readback Voltage Resolution (% of Vo Rated) Resolution (Readback Voltage) Accuracy (0.05% of Vo Rated) 4. Readback Current Resolution (% of lo Rated)	W mV mV mV mV mV mV mV mV mV	OVP/UV On/Off, Address Re-start Baud ra Voltage Current Voltage  * with RS 8 0.16 4  **1200  0.002 0.16 4  0.003 12.00	L manua Output selectic modes te selectic modes te selectic 4 digits 4 digits 7 curren 10 0.2 5 0.001 1.10 5 0.004 13.20	1 adjust on/on/on/on/on/on/on/on/on/on/on/on/on/o	by Volt. ie-start nitrage (or ticresta 0,2400,4 acy: 0.05 cy: 0.2% Fine, Pro  Option: 20 0.4 10 3.3 495 0.006 1.20 10	Adjust en adjust	ncoder. uto, safe adjust node). 0 and 19 de doutput oldback, 1.7 255 0.003 1.20 20 0.002 1.70	e), Foldbencoder.  9,200.  ut Voltag current: Local, C  erface In  60  1.2  30  0.002  1.10  0.002  1.10	stalled 80 1.6 40 0.002 1.60 40 0.003 1.26	100 2 100 100 2 0.011 11.00 50	150 3 75 0.044 66 0.007 10.50 75	200 4 100 0.006 12.00 1.16	300 6 150 0.22 33 0.004 12.00 150	0.11 16.5 0.002 12.00 300 0.002 0.11									
1.Control functions  2.Display 3.Indications 1.6 Interface Specifications for the GENESY 1. Remote Voltage Programming (16 bit) Resolution (0.002% of Vo Rated) Accuracy (0.05% of Vo Rated) (*14) 2. Remote Current Programming (16 bit) Resolution (0.002% of lo Rated) Accuracy (0.2% of lo Rated+0.1% of lo Actual- 3. Readback Voltage Resolution (% of Vo Rated) Resolution (Readback Voltage) Accuracy (0.05% of Vo Rated) 4. Readback Current Resolution (Readback Current)	W mV mV mV mV mV mV mV mV	OVP/UV On/Off, Address Re-start Baud ra Voltage Current Voltage  with RS 8 0.16 4 (*1200  0.002 0.16 4  0.003 12.00 1200	L manua Output 1: selectic modes te selectic : 4 digits: 4 digits: 5: 4 digits: 7: 4 digits: 4 digits: 7: 4 d	1 adjust on/off, R on/off, Accura , Accu	by Volt. e-start n trage (or tic resta 0,2400,4 acy: 0.05 cy: 0.2% Fine, Pro  Optiona 20 0.4 10  3.3 495  0.006 1.20 10  0.007 11.55 495	Adjust en nodes (a current rt, safe r 800,960 % of rated eview, F 30 0.6 15 2.2 330 0.004 1.20 15 0.01 11.00 330	uto, safe adjust uto, safe adjust uto, safe adjust uto, safe adjust uto deb. 0 and 19 adjust uto	e), Foldberncoder.  2),200.  2),200.  2),200.  2),200.  2),200.  2),200.  30  2),200.  30  30  0.002  1.10  165	stalled 80 1.6 40 0.002 1.60 40 0.003 1.26 1.26	100 2 50 0.066 99 0.001 11.00 50 0.004 1.32 99	150 3 75 0.44 66 0.007 10.50 75	200 4 100 0.33 49.5 0.006 1.16 49.5	300 6 150 0.22 33 0.004 12.00 150	0.11 16.5 0.002 12.00 300 0.002 0.11 16.5									
1.Control functions  2.Display 3.Indications 1.6 Interface Specifications for the GENESY 1. Remote Voltage Programming (16 bit) Resolution (0.002% of Vo Rated) Accuracy (0.05% of Vo Rated) (*14) 2. Remote Current Programming (16 bit) Resolution (0.002% of lo Rated) (*14) 3. Readback Voltage Resolution (% of Vo Rated) Resolution (% of Vo Rated) Accuracy (0.05% of Vo Rated) 4. Readback Current Resolution (% of lo Rated) 8. Resolution (% of lo Rated) 4. Resolution (% of lo Rated) 8. Resolution (Readback Current) 9. Resolution (Readback Current) 1. Resolution (Readback Current)	W mV mV mV mV mV mV mV mV mV	OVP/UV On/Off, Address Re-start Baud ra Voltage Current Voltage  * with RS 8 0.16 4  **1200  0.002 0.16 4  0.003 12.00	L manua Output selectic modes te selectic modes te selectic 4 digits 4 digits 7 curren 10 0.2 5 0.001 1.10 5 0.004 13.20	1 adjust on/on/on/on/on/on/on/on/on/on/on/on/on/o	by Volt. ie-start nitrage (or ticresta 0,2400,4 acy: 0.05 cy: 0.2% Fine, Pro  Option: 20 0.4 10 3.3 495 0.006 1.20 10	Adjust en adjust	ncoder. uto, safe adjust node). 0 and 19 de doutput oldback, 1.7 255 0.003 1.20 20 0.002 1.70	e), Foldbencoder.  9,200.  ut Voltag current: Local, C  erface In  60  1.2  30  0.002  1.10  0.002  1.10	stalled 80 1.6 40 0.002 1.60 40 0.003 1.26	100 2 100 100 2 0.011 11.00 50	150 3 75 0.044 66 0.007 10.50 75	200 4 100 0.006 12.00 1.16	300 6 150 0.22 33 0.004 12.00 150	0.11 16.5 0.002 12.00 300 0.002 0.11									

<sup>\*1:</sup> Minimum voltage is guaranteed to maximum 0.2% of rated output voltage. \*2: Minimum current is guaranteed to maximum 0.4% of rated output current. \*3: For cases where conformance to various safety standards (UL, IEC, etc.) is required, to be described as 190-240Vac (50/60Hz) for single phase and 3-Phase 208V models, and 380-415Vac (50/60Hz) for 3-Phase 400V models. \*4: Single-Phase and 3-Phase 208V models: At 208Vac input voltage. 3-Phase 400V: At 380Vac input voltage. With rated output power. \*5: Not including EMI filter inrush current, less than 0.2mSec. \*6: Single-Phase and 3-Phase 208V models: 170~265Vac, constant load. 3-Phase 400V models: 342-460Vac, constant load. \*7: From No-Load to Full-Load, constant input voltage. Maximum drop in Remote Sense.

4 | GENESYS\*\*\* | 3.3kW

<sup>\*8:</sup> For 8V~300V models: Measured with JEITA RC-9131A (1:1) probe.

<sup>\*\*15:</sup> For 8V~300V models: Measured with 10:1 probe.

\*\*9: From 10% to 90% or 90% to 10% of Rated Output Voltage, with rated, resistive load.

\*\*10:From 90% to 10% of Rated Output Voltage.

\*\*11: For load voltage change, equal to the unit voltage rating, constant input voltage.

\*\*12: For 8V~15V models the ripple is measured from 2V to rated output voltage and rated output current. For other models, the ripple is measured at 10~100% of rated output voltage and rated output current.

<sup>\*13:</sup> The Constant Current programming readback and monitoring accuracy does not include the warm-up and Load regulation thermal drift.

\*14: Measured at the sensing point.



## General Specifications Genesys™ 3.3kW

2.1 INPUT CHARACTERISTICS	GEN		10-330					60-55	80-42	100-33	150-22	200-16.5	300-11	600-5.5
			hase,230											
. Input voltage/freq. (*3)	VAC	3-Phase, 208V models: 170~265Vac, 47~63Hz												
		3-Phase	, 400V m	odels: 34	2~460Va	ic, 47~63	Hz							
2. Maximum Single Phase,230V models	S:	24	24	24	24	23	24	23	23.5	23	23	23	23	23
nput current3-Phase, 208V models: at 100% load 3-Phase, 400V models:	Α	14.5	14.5	14.5	14.5	14	14.5	13.6	14	13.7	13.7	13.7	13.8	13.9
t 100% load 3-Phase, 400V models:		7.2	7.2	7.2	7.2	7.0	7.2	6.8	7.0	6.8	6.8	6.8	6.9	7.0
Power Factor (Typ)		Single P	ingle Phase models: 0.99@230Vac, rated output power. 3-Phase models: 0.94@208/380Vac, rated output power.											
. Efficiency (*4)	%	82	83	83	83	86	86	88	88	88	87	87	87	87
Inrush Current (*5)	Α	Single-F	hase and	3-Phase	208V m	odels: Le	ss than 5	0A						
, ,	A	3-Phase	400V mo	dels: Les	ss than 2	0A								
. Hold-up time (Typ)														
.2 POWER SUPPLY CONFIGURATION														
. Parallel Operation		Up to 4	identical	units in I	master/s	lave mod	le							
. Series Operation		Up to 2	identical	units. wi	th exterr	nal diode	s. 600V N	lax to Ch	assis gro	und				
.3 ENVIRONMENTAL CONDITIONS														
. Operating temp		0~50°C.	100% lo	ad.										
. Storage temp		-20~85°												
. Operating humidity			RH (non	-conden	sing).									
. Storage humidity			RH (non											
Vibration		l	F, metho		٠,	is fixed	to the vil	orating s	urface.					
. Shock			in 20G , h											
. Altitude									00m abo	ve 2000i	n, Altern	atively, c	lerate ma	aximum a
			100m abo									- // -		
RoHS Compliance		'	es with th				,		-					
.4 EMC														
Applicable Standards:														
ESD		IEC1000	1 1 2	Air-discl	9 0 K/V	conta	ct							
Fast transients			KV IEC1			conta								
.Surge immunity			ne to li											
.Conducted immunity		IEC1000		BV IEC										
Radiated immunity		EN6100	-,	1A/m		1000-4-1								
Magnetic field immunity			0-4-6, 2A, FC			VCCI-								
Voltage dips		l	ZA, FCC p		,		Α.							
Conducted emission		LINSSUZ	2A, FCC	Jail 13-A	, VCCI-A	•								
0. Radiated emission														
.5 SAFETY														
.Applicable standards:														
			0-1, CSA											
		Mand ed &	χ <u>i</u> th Vοι	ut 50V: C	Output is	SELV, a	ll commi	ınication	/control	interface	es (RS232	2/485, IEI	EE, Isolat	ed Analo
		MANING NOTE: NOTE: MELLING AND												
Interface classification		Models with 60V Vout 400V: Output is Hazardous, communication/control interfaces: RS232/485, IEEE, Isolated												
criace classification		Apples LAN												
		Remote, Programing and Monitoring (pins-1-3, pins14-16) are SELV, Sense, Remote Programming and Monitoring (pins 8-13,												
		pins 21-25) are Hazardous.												
						Output	s Hazarı	الد عييما	commu	nication	control	interface	c (BS22	)/485 IE
		Models with 400V <vout (rs232="" 485,="" 600v:="" all="" communication="" control="" hazardous,="" ieee<="" interfaces="" is="" output="" td=""></vout>												
		Isolated Analog, LAN, Sense, Remote Programming and Monitoring) are Hazardous.												
		Vout 50V models: Input-Output (SELV): 4242VDC 1min, Input-communication/control (SELV):												
Withstand voltage		vout .	70 V 1110	ueis .	iiiput-c	utput	(JLLV).	7272VD		i, ilipui	commi	unicatio	II/ COIICI	OI (SEE
		4242VE	C 1min											
		Input-Ground: 2828VDC 1min,												
		60V <vout (hazardous):="" (selv):<="" 100v="" 1min,="" 2600vdc="" control="" input-communication="" input-output="" models:="" td=""></vout>												
la a dati a a vasiata a s														
Insulation resistance		BX8655	C <sub>28</sub> 178VD	Cantput(	Hazardo	us)-SELV	: 1900V[	C 1min	, Output	(Hazardo	ous)-Grou	und: 120	OVDC 1	min, Inp
6 MECHANICAL CONSTRUCTION Cooling		#007/51	(ഖർ ഗ്രവ	/models	i lanut-C	Ntout(H	azardone	r_3550\/F	(Lmin	lnaut-co	namajunic:	ation/cor	ntrola(SFI	<b>Д</b> у.о.сі
			49416009 6-1-25-200											
. Dimensions (WxHxD) . Weight		ODUTATION OF	Mn1,nh1n88 Hazardo	us)-Grove	131 <b>2/3/17/1</b> 7/1 nd• 267∩	ιψ <b>ειχέπιπά</b> ! VDC 1 mi	ung@otnom n Innut-	account (eli	1828//DC	teandles,l	ettt),	100Mob	m at 25°	C 70% B
. Weight . AC Input connector (with Protective C	over)												ut 23	-, / U / U N
Output connectors		3-Phase	hase,230 , 208V &	400V mo	s, Fower dels, Pov	ver Com	oicon PC	o/ 3-GF-1 6-16/4-G	o, 10 serie F-10,16 s	eries, with S eries, wit	th Strain	relief.		
2.7 RELIABILITY SPECS			00V mode										enix P/N	: FRONT
. Warranty														
ll specifications subject to change with	out no													
		5 years.												



#### Genesys<sup>™</sup> Power Parallel and Series Configurations

#### Parallel operation - Master/Slave:

Active current sharing allows up to four identical units to be connected

in an auto-parallel configuration for four times the output power.

In Advanced Parallel Master/Slave Mode, total current is programmed and reported by the Master, Up to four supplies act as one.





#### Series operation

Up to two units may be connected in series to increase the output voltage or to provide bipolar output. (Max 600V to Chassis Ground).

#### Remote Programming via RS-232 & RS-485 Interface

Standard Serial Interface allows daisy-chain control of up to 31 power supplies on the same communication bus with





#### **Programming Options (Factory installed)**

#### Digital Programming via IEEE Multi-Drop Interface

- Allows IEEE Master to control up to 30 slaves over RS-485 daisy-chain
- Only the Master needs be equipped with IEEE Interface
- IEEÉ 488.2 SCPI Compliant
- Program Voltage
- Measure Voltage
- Over Voltage setting and shutdown
- Error and Status Messages

- Program Current
- Measure Current
- Current Foldback shutdown

#### **Isolated Analog Programming**

Four Channels to Program and Monitor Voltage and Current. Isolation allows operation with floating references in harsh electrical environments. Choose between programming with Voltage or Current.

Connection via removable terminal block: Phoenix MC1,5/8-ST-3.81.

• Voltage Programming, user-selectable 0-5V or 0-10V signal. P/N: IS510

Power supply Voltage and Current Programming Accuracy ±1% Power supply Voltage and Current Monitoring Accuracy ±1.5%

• Current Programming with 4-20mA signal.

Power supply Voltage and Current Programming Accuracy ±1% Power supply Voltage and Current Monitoring Accuracy ±1.5%

# LAN Interface Compliant to Class C

- Meets all LXI-C Requirements
- Address Viewable on Front Panel
- Fixed and Dynamic Addressing
- Compatible with most standard Networks
- TCP / UDP Socket Programming

#### P/N: LAN

- VISA & SCPI Compatible
- LAN Fault Indicators
- Auto-detects LAN Cross-over Cable

P/N: IS420

Fast Startup

P/N: IEEE



#### Power Supply Identification / Accessories How to order

GEN	8	<u>400 -</u>	<u>.                                      </u>	<u> </u>
			Factory Options:	Factory AC Input Options:
Series	Output	Output	Option: IEEE	1P230 (Single Phase 170~265VAC)
Name	Voltage	Current	IS510	3P208 (Three Phase 170~265VAC)
	(0 ~ 8V	(0~400A)	IS420	3P400 (Three Phase 342~460VAC)
	, -	,	LAN	

#### **Models 3.3kW**

Model	Output Voltage VDC	Output Current ( A )	Outpu t Power (W)
GEN 8-400	0~8V	0~400	3200
GEN 10-330	0~10V	0~330	3300
GEN 15-220	0~15V	0~220	3300
GEN 20-165	0~20V	0~165	3300
GEN 30-110	0~30V	0~110	3300
GEN 40-85	0~40V	0~85	3400

Model	Output Voltage VDC	Output Current ( A )	Outpu t Power (W)
GEN 60-55	0~60V	0~55	3300
GEN 80-42	0~80V	0~42	3360
GEN 100-33	0~100V	0~33	3300
GEN 150-22	0~150V	0~22	3300
GEN 200-16.5	0~200V	0~16.5	3300
GEN 300-11	0~300V	0~11	3300
GEN 600-5.5	0~600V	0~5.5	2200

#### P/N **Factory option**

RS-232/RS-485 Interface built-in Standard

IEEE **GPIB** Interface Voltage Programming Isolated Analog Interface IS510 Current Programming Isolated Analog Interface IS420 LAN Interface (Complies with Class C) LAN

#### Accessories

#### 1. Serial Communication cable

RS-232/RS-485 cable is used to connect the power supply to the Host PC.

Mode	RS-485	RS-232	RS-232
PC Connector Communication Cable Power Supply Connector	DB-9F Shield Ground L=2m EIA/TIA-568A (RJ-45)	DB-9F Shield Ground L=2m EIA/TIA-568A (RJ-45)	DB-25F Shield Ground EIA/TIA-568A (RJ-
P/N	GEN/485-9	GEN/232-9	45) GFN/232-25

#### 2. Serial link cable\*

Daisy-chain up to 31 Genesys<sup>™</sup> power supplies.

Mode	Power Supply Connector	Communication Cable	P/N
RS-485	EIA/TIA-568A (RJ-45)	Shield Ground L=50cm	GEN/RJ45

<sup>\*</sup> Included with power supply




Also available, Genesys™ 1U Half Rack 750W 1U full Rack 750W/1500W/2400W 2U full Rack 5000W




### TDK-Lambda

# Outline Drawing Genesys™ 3.3kW Units


POWER







### TDK-Lambda



#### NOTE

- 1. Bus bars for 8V to 100V models (shown) Wire clamp connector for 150V to 600V models
- 2. Plug connectors included with the power supply
- 3. Chassis slides mounting holes #10-32 marked "A" GENERAL DEVICES P/N: C-300-S-116 or equivalent



# Contactgegevens

Spaarpot 149
5667 KW Geldrop
+ 31 (0)40 851 2170
info@BMF-systemparts.com